



EKO BRILL T6

Soaping agent for ultrasounds

Specific for:
ZAMAK, BRASS

Application

- Specific soaping agent for ultrasonic cleaning for zamak and brass
- Excellent protective action to treated tools, with high protection barrier. The zamak can even stay in the solution of Ekobrill T6 for a few hours
- Product to be used only in demineralized (soft) water
- High active concentration that allows to work at concentrations 2/3%
- Excellent stable quality of the solution (we guarantee stable quality of the bath with replacement after double time compared to normal detergents)
- Easy rinsing

Physico-Chemical data

- Physical state: VISCOUS LIQUID
- Color: YELLOW
- Odour: TYPICAL LIGHT
- Density: 1.040 Gr/ml
- Ph sol.3%: 9,5
- Solubility in water: TOTAL